


SITI

SPA

SOCIETÀ ITALIANA TRASMISSIONI INDUSTRIALI



BH - MBH



Montage – Center

Max Lamb GmbH & Co. KG

Am Bauhof

97076 Würzburg

Tel. 0931 / 2794 - 0

Fax. 0931 / 2794 - 261

email: ant@lamb.de



**INSTALLATION, OPERATION and
MAINTENANCE MANUAL**

09.2008

We, at SITI S.p.A., would like to thank you for the confidence shown in choosing our products. Our dedication to quality and innovation have allowed us to develop highly efficient gearboxes capable of satisfying even the most demanding requirements.

Carefully reading and becoming familiar with the contents of this manual is of prime importance for trouble-free operation.

If, after thoroughly reading this manual, some topics are not clear please do not hesitate to contact our Customer Service Department or Service centers for more detailed information.

Copyright. Unauthorized reproduction can result in civil damages and criminal prosecution. The contents of the manual and drawings are valuable trade secrets and must not be given to third parties, copied, reproduced, disclosed or transferred unless duly authorized by SITI S.p.A. in writing in advance.

MANUFACTURER'S DATA



SOCIETÀ ITALIANA TRASMISSIONI INDUSTRIALI ®

GEARBOXES
MOTORIZED GEARBOXES
SPEED VARIATORS
ELECTRIC C.A./C.C. MOTORS
COUPLINGS

HEADQUARTER

Via G. Di Vittorio, 4
40050 Monteveglio - BO - Italy
Tel. +39/051/6714811
Fax. +39/051/6714858
E-mail: info@sitiriduttori.it
WebSite: www.sitiriduttori.it

CONTACTING OUR SERVICE DEPARTMENT

When contacting our customer service department always quote the data indicated on the gearbox's identification plate.

Contents

MANUFACTURER'S DATA	2
CONTACTING OUR SERVICE DEPARTMENT	2
1 GENERAL INFORMATION	4
1.1 CONTENTS OF THE MANUAL	4
1.2 USERS OF THE MANUAL	4
1.3 HOW TO CONSULT THE MANUAL	4
1.4 WORKING WITH THE USER	5
1.5 UPDATED VERSIONS OF THE MANUAL	5
1.6 SELECTING PERSONNEL AND PERSONNEL QUALIFICATION LEVELS	5
1.7 RESIDUAL RISKS	5
1.8 SALES CONDITIONS AND WARRANTY	5
2 SAFETY INFORMATION	6
2.1 SAFETY PRECAUTIONS	6
3 DESCRIPTION	7
3.1 INTENDED USE	7
3.2 FORBIDDEN AND ERRONEOUS USE	7
3.3 GEARBOX IDENTIFICATION DATA	7
3.3.1 HOW TO READ AND SAVE THE PLATES	7
3.4 SPECIFICATIONS	7
4 INSTALLATION INSTRUCTIONS	8
4.1 OPERATIONS TO BE PERFORMED BEFORE INSTALLING THE GEARBOXES (BY THE CUSTOMER)	8
4.1.1 GEARBOX SHIPMENT, UNLOADING AND HANDLING	8
4.2 DECOMMISSIONING AND DISPOSAL	8
4.3 INSTALLATION INSTRUCTIONS	8
4.4 ASSEMBLING AND REMOVAL OF HOLLOW-SHAFT GEAR UNITS	9
4.4.1 ASSEMBLING OF HOLLOW-SHAFT GEAR UNITS (FIG. A)	9
4.4.2 REMOVAL OF HOLLOW SHAFT GEAR UNITS (FIG. B)	9
5 GEARBOX OPERATING INSTRUCTIONS	10
5.1 IMPORTANT SAFETY INFORMATION	10
5.2 BEFORE STARTING THE GEARBOXES	10
6 MAINTENANCE	11
6.1 ROUTINE AND SCHEDULED MAINTENANCE	11
6.2 CLEANING	11
6.3 OPERATING TEMPERATURE	11
6.4 MEASURING THE OPERATING TEMPERATURE	11
6.5 CHECKING THE LUBRICANT LEVEL	12
6.6 REPLACING THE SEALS	12
6.7 LUBRICATION	13
6.7.1 LUBRICANT CHART	13
6.7.2 OIL QUANTITY (LT)	13
6.8 MOUNTING POSITION	14
6.9 POSITION OF TERMINAL BOX	14
6.10 TIGHTENING TORQUE CHART	14
6.11 TROUBLESHOOTING GUIDE	15
7 REPLACEMENT PARTS	16

1 GENERAL INFORMATION

We, at SITI S.p.A., would like to thank you for choosing our products. Our dedication to quality and innovation have allowed us to develop highly efficient gearboxes capable of satisfying even the most demanding requirements.

Installation personnel must thoroughly read and familiarize themselves with the contents of this entire manual.

If in doubt, please do not hesitate to contact our Customer Service Department or Service centers for more detailed information.

1.1 CONTENTS OF THE MANUAL

This manual contains a description of the gearbox, information about “intended use” and performance along with the specifications and installation, operation and maintenance instructions.

1.2 USERS OF THE MANUAL

This publication is aimed at:

- the factory supervisor/installation personnel
- operators
- maintenance personnel

The person performing the job must keep the manual nearby where it can be easily consulted and kept in good condition. If the manual is lost or ruined, contact the MANUFACTURER to obtain another copy quoting the serial number of the gearbox.

1.3 HOW TO CONSULT THE MANUAL

The instructions are accompanied by icons that aid in reading the manual. In fact, these icons indicate the type of information provided, more precisely:



Danger!

This icon indicates: failure to heed the safety standards and follow the instructions given may cause accidents. Carefully read and follow the instructions provided with this icon, exercising extreme caution at all times.

 **This icon indicates important information on how to properly handle, install, use and maintain the gearbox.**



This icon indicates the order given must be followed.

When necessary the text includes the numbers of the figures that identify the illustrations provided in the manual. The parts of the gearbox described in the text are identified with numbers.

E.g.: - 1 - (fig. 1) means part of component 1 in figure 1.

1.4 WORKING WITH THE USER

The manufacturer is at the customer's disposal to answer any questions and provide any additional information needed. In addition we gladly accept any suggestions to improve this manual to make it more comprehensible and better satisfy the purposes it is designed for. If the equipment changes hands, please send the manufacturer the new owner's address so that he can receive any information, supplements and/or updates.

1.5 UPDATED VERSIONS OF THE MANUAL

This manual deals with the state-of-the-art condition of the gearbox it is in at the time it is put on the market. The manual is to be considered a fundamental part of the gearbox and complies with all laws, directives and standards currently in force. It cannot be considered inadequate only because updated later on based on new information. If any modifications, changes, etc.. are made to gearboxes sold later on the manufacturer shall not be held liable for modifying equipment previously supplied nor shall the gearbox and relative manual be considered incomplete and inadequate. Any supplements the manufacturer sends to the users should be kept along with the manual that is part of the gearbox.

PROPER OPERATION AND TOP PERFORMANCE OF THE GEARBOX IS OBTAINED ONLY IF ALL THE INSTRUCTIONS GIVEN IN THIS MANUAL ARE CAREFULLY AND COMPLETELY FOLLOWED.

1.6 SELECTING PERSONNEL AND PERSONNEL QUALIFICATION LEVELS

The operators responsible for handling, installing and servicing the gearboxes on their own must meet the requirements given below:

- minimum work age as specified by laws in force at the time of use
- well-educated and trained on how to properly and safely perform the jobs
- have completely read and become familiar with the contents of this manual
- have been instructed and fully understand the accident prevention laws in force at the time of use
- be physically able to carry out the jobs
- always wear certified personal safety gear

1.7 RESIDUAL RISKS

Assessment of the risks the operators responsible for operating and maintenance may face was carried out during the design stage. All the necessary precautions have been taken to make the machine safe and reliable. Risk assessment has not shown any particular residual risks.

1.8 SALES CONDITIONS AND WARRANTY

As regards all the commercial and legal aspects, consult the catalogue for the gearbox in question.

2 SAFETY INFORMATION

In compliance with Machinery Directive EEC 89/392 article 4.2 and annex II°/sub B, as the gearboxes dealt with in this certificate are incorporated and/or assembled in other machines they are considered “components” therefore:

THEY CANNOT BE STARTED UP UNTIL THE MACHINE THEY ARE INSTALLED IN HAS BEEN CERTIFIED THAT IT COMPLIES WITH MACHINERY DIRECTIVES 89/392/CEE, 91/368/CEE, 93/44/CEE AND 93/68/CEE.

Note:

The product included in this certificate meets the essential requirements given above and those of the catalogue in force as of the date of production. SITI S.p.A. reserves the right to modify them according to changes in technology and materials.

- The gearbox must not be modified unless duly authorized by the manufacturer.
- Carefully read the instructions given in this manual before attempting to move the gearbox, especially when it weighs more than 25 kg.

Warning!

Some gearboxes may be supplied without oil; they must be filled with oil immediately. Consult paragraph “6.7 Lubrication” for more specific information regarding the type and amount of lubricant required.



2.1 SAFETY PRECAUTIONS



Danger!

Only specially trained operators are authorized to install, connect, start up, carry out maintenance or repair the gearboxes. In any case, the steps below must be closely followed:

- Follow the instructions provided by the manufacturer.
- Observe the warning and alert symbols given on the gearboxes.
- Read and become familiar with the contents of the User's Manuals.
- Observe the specific standards for the plant.
- Observe the all standards currently in force (explosion protection, safety, risk prevention).

3 DESCRIPTION

3.1 INTENDED USE

The machine is designed for industrial use under normal environmental conditions.

3.2 FORBIDDEN AND ERRONEOUS USE

The gearbox must not be used in areas whose atmosphere is potentially explosive.

3.3 GEARBOX IDENTIFICATION DATA

All our gearboxes come with one or more plates that have the identification data stamped on them.

3.3.1 HOW TO READ AND SAVE THE PLATES

The data given on the plates must be legible at all times. Clean them on a regular basis. If a plate is worn and/or no longer legible, even if just one item, contact the manufacturer to obtain a replacement plate. When ordering, always quote the data given on the original plate.

Data contained on the nameplate:

- TYPE: Logo of the Gearbox.
- N° : Number
- RATIO: Reduction Ratio
- COD: Gearbox code description

SITI ®		MADE IN ITALY
		www.sitiriduttori.it
TIPO TYPE	<input type="text"/>	
N°	RAPP. RATIO	<input type="text"/>
COD.	<input type="text"/>	

Warning!

The plates must never be removed.

3.4 SPECIFICATIONS

Gearbox dimensions and performance

See the relative manual.

Airborne noise level

The airborne noise level when running under full load under the most adverse operating conditions is still considerably lower than 85 dB.

4 INSTALLATION INSTRUCTIONS

The gearboxes are delivered entirely factory assembled. Only specially trained personnel are authorized to install, assemble and start them up.

4.1 OPERATIONS TO BE PERFORMED BEFORE INSTALLING THE GEARBOXES (BY THE CUSTOMER)

Preparation

In order to install the gearbox, carry out the operations given on the confirmation before hand:

- Make sure the structures are adequate in relation to the actions and reactions deriving from use of the gearbox.
- Make sure the installation site is adequate and enough space is available.
- Make sure that the mounting position indicated in the order confirmation corresponds to the requested one.

4.1.1 GEARBOX SHIPMENT, UNLOADING AND HANDLING

Always check the goods to make sure they were not broken or damaged during shipment before handling the gearbox.



Danger!


The gearbox is delivered factory assembled and packed.

If the product is packed in cardboard cases, use lift equipment that complies with safety regulations to handle the product.

To handle unpacked products, use lift equipment suitable for weights heavier than **30 kg**. In any case, pay careful attention not to accidentally bang surfaces and coupling parts. Use the eyebolt when needed (parts heavier than **30 kg**).

The eyebolt can lift just the gearbox and not the parts it will be attached to. Regarding gearboxes that weigh more than **30 kg** not equipped with an eyebolt, a suitable eyebolt should be used to lift them in complete safety. Otherwise exercise extreme caution and use slings to lift the gearboxes.

The types of eyebolts are given in the chart.



EYEBOLTS	
BH 63	M10
BH 80	M10
BH 100	M12
BH 125	M12
BH 140	M20
BH 160	M20
BH 180	M24
BH 200	M24

4.2 DECOMMISSIONING AND DISPOSAL

When the gearbox has reached the end of its expected service life, it should be disassembled and disposed of. Drain the lubricant from the gearbox. Remember that oil greatly pollutes the environment.

Once decommissioned, dispose of the materials and oil in compliance with current environmental protection laws and standards.

Specialised companies should be contacted when disposing of materials. The user is responsible for assuring the company contracted is authorized and certified to handle toxic materials.

4.3 INSTALLATION INSTRUCTIONS

The position in which the gearbox is to be installed is given in paragraph 6.8.

4.4 ASSEMBLING AND REMOVAL OF HOLLOW-SHAFT GEAR UNITS

4.4.1 ASSEMBLING OF HOLLOW-SHAFT GEAR UNITS (FIG. A)

- Clean the shaft.
- Lubricate the shaft with Klüber paste 46MR401 (or equivalent).
- Assemble the circlip, item 1.
- Insert the washer, item 2.
- Screw the retaining screw, item 3.




Fig. A

4.4.2 REMOVAL OF HOLLOW SHAFT GEAR UNITS (FIG. B)

- First of all remove the fixing items indicated in the “assembling” paragraph (screw 3, washer 2 and circlip 1)(fig. A).
- Insert the washer, item 4.
- Insert the jack nut, item 5.
- Assemble the circlip, item 1.
- Screw the removal screw, item 3.




Fig. B

 **Note:**

All the mentioned components are included in the assembling/removal kit, that can be ordered as an optional.

5 GEARBOX OPERATING INSTRUCTIONS

5.1 IMPORTANT SAFETY INFORMATION

Make certain the following requirements are observed when installing the gearbox:

During installation the following must NOT be present: potentially explosive atmosphere, oils, acids, vapors, radiation.

**The position in which the gearbox is installed can be changed only after contacting the manufacturer.
The warranty will expire in case of missing consultation with the manufacturer.**



Danger!

Only specially-trained personnel are authorized to install and start up the gearboxes. Incorrect installation may put the operator's safety at jeopardy and seriously or irreparably damage the equipment and machine it is connected to.

Carefully follow the precautions given below:

Before attempting to carry out any operations, make certain the plant or drive motor is disconnected from the supply mains and that the machine is not energized.

Remember that the gearbox should never be operated without oil or when its parts are disconnected. In addition, do not put the gearbox in water or corrosive solutions.

Make sure the amount of lubricant, its viscosity index and position of the filler and drain plugs are adequate for the position in which the gearbox is installed and operating conditions present. In addition, do not use toxic oils and never mix two different types of oils together.

When installing the gearbox, always leave enough room free so that it can be periodically checked and maintenance can be conveniently performed. It is also important that air is able to flow freely to assure good ventilation and heat dispersion. The product should be installed in the position indicated on the order.



Danger!

Make sure the gearbox is well-secured to the framework to assure vibration-free operation. In addition, it should be mounted on machined surfaces. Use systems that prevent the clamp screws from coming loose.

Be extremely careful to perfectly align the gearbox with the motor and machine to be driven. Use flexible or self-aligning couplings where possible. If the gearbox risks being hit, overloaded for a prolonged time or blocked, install overload cut-outs, torque limiters, hydraulic couplings or other similar devices.

5.2 BEFORE STARTING THE GEARBOXES

Checks to be performed

The list given below describes all the checks to be made before attempting to start the gearbox.

- Inspect the packaging to check the goods upon delivery.
- Does the installation position match the value given in the gearbox plate?



Warning!

**The position in which the gearbox is installed can be changed only after contacting the manufacturer.
The warranty will expire in case of missing consultation with the manufacturer.**

- Does the correct oil level in the installation position correspond to the amount of oil stated in the gearbox manual?
- Can the oil drain (where provided) and inspection plugs along with the release valves be easily reached?

6 MAINTENANCE

The maintenance schedule includes routine and periodic operations. Routine maintenance refers to operations during which the operator and/or specially trained maintenance workers have to inspect and check the parts. When performing periodic maintenance the operators have to replace, adjust and lubricate parts. The manufacturer holds specific training courses and provides publications to fully instruct the maintenance staff on how to perform the jobs correctly and in complete safety.


6.1 ROUTINE AND SCHEDULED MAINTENANCE

Periodically check the outer surfaces of the gearbox and the cooling air passages for cleanliness. Regularly make sure that no lubricant leaks through the seals, mounting flanges, mounting screws of the covers, caps etc..

Warning!

If the gearbox is run without enough lubricant, it may be seriously and often irreparably damaged.

Efficiency of the heat exchange process is notably affected if the oil inside the gearbox is too low. As heat dissipation and the cooling capacity are considerably reduced, the inside operating temperature increases above all at the points where the sides of the teeth come into contact.




6.2 CLEANING

Clean the gearbox casing on a regular basis to assure good heat exchange with the outside.

6.3 OPERATING TEMPERATURE


The operating temperature depends on a number of factors such as the type of power transmission, the type and quantity of lubricant, the characteristics and structure of the gearbox, the speed and power applied and the environment in which the gearbox is operating.

When ring seals made of nitrile rubber compounds are installed, it is not a good idea to run the gearbox at temperatures above +85 °C. Therefore, if the temperature inside the gearbox reaches more than +85 °C for significant lengths of time, a special version needs to be requested with ring seals in fluoridated compounds (viton).



6.4 MEASURING THE OPERATING TEMPERATURE


Wherever possible, suitable instruments should be used to measure the external temperature of the gearbox housing. As, under optimum operating conditions, there is a rise in temperature of 20-40 °C inside the gearbox compared to outside, the housing normally becomes too hot to touch. It is therefore wrong to assume that the gearbox is too hot just because it cannot be touched. In fact, it cannot be touched as soon as the temperature goes above 50 °C. It is important to check that the operating temperature when the gearbox runs at normal speed, when the operating conditions remain the same, is more or less constant. This indicates that the gearbox is running in a trouble-free manner.



6.5 CHECKING THE LUBRICANT LEVEL

Regularly check that the oil level is correct when the gearbox has stopped and cooled down sufficiently. To do this, use the sight-glass provided. This should be kept clean and be see-through at all times (see par. 6.8). When looking through the sight-glass, if it seems as though there are deposits in the oil, make sure that no foreign bodies such as dust, sand or water have got inside the gearbox housing. If the oil level has fallen below the minimum level, top up immediately. If the gearbox is run without enough lubricant, it may be seriously and often irreparably damaged.

Efficiency of the heat exchange process is notably affected if the oil inside the gearbox is too low. As heat dissipation and the cooling capacity are considerably reduced, the inside operating temperature increases above all at the points where the sides of the teeth come into contact.



6.6 REPLACING THE SEALS

The efficiency and service life of the ring seals largely depends on the operating temperature in the contact zone, any chemical reactions which may occur between the rubber compound and the lubricant and, finally, its wear condition.


The ring seals need to be replaced when:

- the seal is no longer efficient and, as a result, oil is leaking out;
- the entire machine or system is overhauled.

Whenever a seal is no longer efficient, it must be replaced immediately to avoid any further leakage and prevent any other parts from being damaged.

When installing the new ring seal, follow the instructions below:

- take great care when handling the seal and make sure it is in good condition (do not leave it in stock for too long as this could cause premature wear especially if it is stored in a damp environment);
- always check that the seat where the seal is to be fitted is perfect i.e. without scoring, marks, nicks, dents or surface defects of any kind;
- make sure the lip of the new seal is not fitted at exactly the same point as the previous one;
- if the area where the ring seal comes into contact with the shaft has worn down by more than 0.2-0.3 mm, do not, under any circumstances, install a new seal but contact our local service centre where the staff will see whether the shaft can still be used and identify the cause of the damage;
- install the ring seal perpendicularly to the shaft, with the lip absolutely free and not curled under or pinched;
- install the ring seal so that the lip faces the oil that must be kept in or the side from where the pressure is exerted;
- for ring seals without a dust-tight lip, coat the outside of the lip with grease;
- for ring seals provided with a dust-tight lip, fill the gap between the seal lip and the dust-tight lip with grease;
- lubricate the seal seat on the shaft;
- do not use sealants because, if they get on the seal lip or shaft surface they can cause rapid wear;
- when installing the seal, press down as near as possible to the outside edge;
- do not block the ring seal axially or apply too much load;
- always use suitable tools to avoid damaging the seal lip with threads, grooves, sharp edges or keyways;
- always cover the seal lip and the seat on the shaft when repainting the gearbox.



All the precautions mentioned above need to be taken in order to prevent the ring seal from becoming dry especially when the shaft first starts to rotate. If the seal becomes dry, the temperatures in the area where it comes into contact with the shaft become too high immediately damaging the seal material and causing the lip to harden, crack and discolour.

6.7 LUBRICATION

The gearboxes supplied by our company without oil are the ones intended for heavy-duty use. In this case, the maintenance procedures to be performed are as follows:

a) running in the gearboxes

The running in time is about 300-400 hours. During this period we recommend gradually increasing the power output up to a limit of 50-70% of the maximum power output (during the first hours of operation). At this stage, the gearboxes may reach higher temperatures than normal. It is advisable to change the oil after the running in period.

b) changing the oil

The time interval at which the oil should be changed depends on the operating conditions. These are outlined in the chart below:

Oil temperature	Duty	Time interval (hours)
<60°C	Continuous	5000
	Intermittent	8000
>60°C	Continuous	2500
	Intermittent	5000

The data indicated in this chart refers to mineral and synthetic lubricants. The latter can be used for long-term lubrication if used within a normal temperature range and as long as they are not ruined by dirt, air, etc. getting inside the gearbox.

6.7.1 LUBRICANT CHART

We recommend to strictly adhere to the table of lubricants mentioned here below:

TABLE 1 - MINERAL LUBRICANTS

MAKE	TYPE OF OIL
• SHELL	OMALA OIL 220
• IP	MELLANA OIL 220
• MOBIL	MOBILGEAR 630
• ESSO	SPARTAN EP220


TABLE 2 - SYNTHETIC LUBRICANTS

MAKE	TYPE OF OIL
• SHELL	TIVELA OIL SC 320
• IP	TELIUM OIL 320
• KLÜBER	SYNTHESO D 320 EP

6.7.2 OIL QUANTITY (lt)

Mounting position	BH							
	63	80	100	125	140	160	180	200
B3	1,8	3,6	7,1	11,0	20,4	31,0	31,0	53,0
B6	3,2	5,2	9,3	15,0	24,4	40,0	52,0	68,0
B7	3,0	4,1	8,5	13,0	23,0	32,0	46,0	65,0
B8	2,0	3,6	5,9	8,5	15,0	15,5	34,0	46,0
V5	1,8	2,7	5,0	7,8	15,0	14,0	34,0	46,0
V6	1,9	2,9	5,7	9,0	16,2	16,5	34,0	53,0


6.8 MOUNTING POSITION




Note

The mounting position must be always pointed out at the time of the order. Should any particular request be missing, the unit will be supplied for the mounting position B3.

6.9 POSITION OF TERMINAL BOX



Standard position



Positions upon request

6.10 TIGHTENING TORQUE CHART

For gearboxes and accessories

Screw threading Class 8.8	Cast and steel twisting moment (Nm)	Aluminium twisting moment (Nm)
M 4	2,9	2,3
M 5	6	4,8
M 6	10	8
M 8	25	20
M 10	49	39
M 12	86	69
M 14	135	108
M 16	210	168
M 18	290	232
M 20	410	328

6.11 TROUBLESHOOTING GUIDE

This chart contains malfunctions that may arise during operation. They are listed according to the individual functions of the gearbox. The trouble, causes and part that may have caused the fault are indicated in the chart.


PROBLEM	POSSIBLE CAUSES	REMEDY
The motor does not start	<ul style="list-style-type: none"> a) The motor's electrical wiring is faulty b) The motor is faulty c) Wrong size motor 	<ul style="list-style-type: none"> a) Check the connections b) Replace the motor c) Replace the motor
The motor and gearbox reach temperatures which are too high	<ul style="list-style-type: none"> a) Mechanical overload b) Wrong size geared motor assembly 	<ul style="list-style-type: none"> a) Check the mechanical parts driven by the geared motor assembly b) Replace the geared motor assembly
The current absorbed and/or the temperature of the motor are too high	<ul style="list-style-type: none"> a) Motor faulty b) Wrong size motor 	<ul style="list-style-type: none"> a) Replace the motor b) Replace the motor
The gearbox reaches a temperature which is too high	<ul style="list-style-type: none"> a) Gearbox faulty b) Wrong size gearbox c) Wrong mounting position d) Not enough lubricant 	<ul style="list-style-type: none"> a) Repair or replace the gearbox b) Replace the gearbox c) Check that the gearbox supplied is that ordered d) Add lubricant until the level indicated is reached
Oil leaks from the shafts	<ul style="list-style-type: none"> a) Ring seals worn down or defective b) Seal seat on the shaft worn 	<ul style="list-style-type: none"> a) Replace the ring seals b) Replace the ring seals and install them in a very slightly different position or replace the shafts
Oil leaks from the seals	<ul style="list-style-type: none"> a) Flanges not tightened properly b) Seals defective 	<ul style="list-style-type: none"> a) Tighten the flanges b) Replace the seals and check that the surfaces are properly machined
The gearbox is making a banging noise.	<ul style="list-style-type: none"> a) Gear teeth defective 	<ul style="list-style-type: none"> a) Contact our customer service department
The gearbox is whistling.	<ul style="list-style-type: none"> a) Not enough lubricant b) Gears defective or worn down c) Bearings defective or not installed properly 	<ul style="list-style-type: none"> a) Add lubricant until the level indicated is reached b) Contact our customer service department c) Contact our customer service department





7 REPLACEMENT PARTS



If used properly and the scheduled maintenance is regularly performed as specified in this manual the gearboxes are designed and engineered not to require spare parts due to faults or break downs.

If some parts need to be replaced, use only original spare parts. The parts are to be removed and re-installed only by specially-trained authorized personnel.

Along with voiding the warranty, use of non-original spare parts may also affect proper operation of the gearbox.



	STANDARD	ON REQUEST						
	12		15	16	19	24	44	50
	Bearing		Shaft seal	Cover	Bearing	Bearing	Bearing	Bearing
BH 63	6010 50x80x16	32012 X 50x80x20	50x80x8	D.47 S.7	30204 20x47x15,25	33205 25x52x22	6208 40x80X18	6208 - 2RS 40x80X18
BH 80	6012 60x95x18	32012 X 60x95x23	<u>60x95x10</u>	D.52 S.7	33205 25x52x22	32305 25x62x25,25	6208 40x80X18	6208 - 2RS 40x80X18
BH 100	6014 70x110x20	33014 70x110x31	70x110x8	D.62 S.10	33206 30x62x25	32306 30x72x28,75	NUP 408 40x110x27	NUP 212 EC NUP 212 AV 60x110x22
BH 125	6018 90x140x24	32018X 90x140x32	90x140x13	D.85 S.10	33209 45x85x32	32306 30x72x28,75	NUP 408 40x110x27	NUP 212 EC NUP 212 AV 60x110x22
BH 140	32021x 105x160x43		105x160x12	D.110 S.10	33212 60x110x38	33209 45x85x32	NJ 2212 EC 60x110x28	6316 - 2RS 80x170x39
BH 160	33024 120x180x48		120x180x15	D.130 S.12	32312 60x130x48,5	32311 55x120x45,5	NJ 2212 EC 60x110x28	6316 - 2RS 80x170x39
BH 180	32026X 130X200X45		130x200x15	D.140 S.15	32313 65X140X51	32312 60x130x48,5	NJ 2213 EC 65x120x31	NJ 316 EC NUP 316 AV 80x170x39
BH 200	33030 150x225x59		150x225x15	D.150 S.15	32314 70x150x38	33215 75x130x41	NJ 2313 EC 65x140x48	NJ 316 EC NUP 316 AV 80x170x39

	55	61	63	67	76		80		83	
	Shaft seal	Bearing	Shaft seal	Bearing	Bearing		Bearing		Shaft seal	
BH 63	40x80x10	6010 - 2RS 50x80x16	65x80x8	6208 40x80x18	PAM 71-80-90	6207 35x72x17	6010 - 2RS 50X80X16		50x65x8	
BH 80	40x80x10	6010 - 2RS 50x80x16	65x80x8	6208 40x80x18	PAM 71-80-90	6207 35x72x17	6010 - 2RS 50X80X16		50x65x8	
BH 100	60x110x12	6212 - 2RS 60X110X22	80x110x10	6408 40x110x27	PAM 80-90	6208 40x80x18	PAM 80-90 100-112	6310 - 2RS 50X110X27	PAM 80-90 100-112	50x90x10
BH 125	60x110x12	6212 - 2RS 60X110X22	80x110x10	6408 40x110x27	PAM 80-90	6408 40x110x27	PAM 132	6212 - 2RS 60X110X22	PAM 132	60x90x8
BH 140	80x170x13	6219 - 2RS 95x170x32	130x170x12	NJ 2212 EC 60x110x28	NJ 2212 EC 60x110x28		6219 - 2RS 95x170x32		95x170x13	
BH 160	80x170x13	6219 - 2RS 95x170x32	130x170x12	NJ 2212 EC 60x110x28	NJ 2212 EC 60x110x28		6219 - 2RS 95x170x32		95x170x13	
BH 180	108x170x15	6219 - 2RS 95x170x32	108x170x15	NJ 2213 EC 65x120x31						
BH 200	108x170x15	6219 - 2RS 95x170x32	108x170x15	NJ 2213 EC 65x120x31						

SITI SPA

SOCIETÀ ITALIANA TRASMISSIONI INDUSTRIALI



RIDUTTORI
MOTORIDUTTORI
VARIATORI CONTINUI
MOTORI ELETTRICI C.A./C.C.
GIUNTI ELASTICI

GEARBOXES
GEARED MOTORS
SPEED VARIATORS
A.C./D.C. ELECTRIC MOTORS
FLEXIBLE COUPLINGS



ITALIA (ITALY)
SEDE e STABILIMENTO
HEADQUARTERS

Via G. Di Vittorio, 4
40050 Monteveglio - BO - Italy
Tel. +39/051/6714811
Fax. +39/051/6714858
E-mail: info@sitiriduttori.it
commitalia@sitiriduttori.it
export@sitiriduttori.it
WebSite: www.sitiriduttori.it



CINA (CHINA)
SEDE e STABILIMENTO
OFFICE AND PLANT

Shang Hai SITI Power Transmission Co.,Ltd.
No. 303 Kangliu Road Kangqiao Industrial Zone
Pudong
Shang Hai, P.R. China P.C.: 201315
Tel. +86-21-68060500
Fax. +86-21-68122539
E-mail: service@sh-siti.com
WebSite: www.sh-siti.com